

## **INT-001-AB-3 Interchange Information**

### **1. Purpose**

The purpose of this *reliability standard* is to require that *interchange* information is submitted to the *interchange authority*.

### **2. Applicability**

This *reliability standard* applies to:

- *ISO*

### **3. Definitions**

Italicized terms used in this *reliability standard* have the same meanings as set out in the Alberta Reliability Standards Glossary of Terms and Part 1 of the ISO Rules.

### **4. Requirements**

**R1** The *ISO* must submit to the *interchange authority*, for an *interchange transaction* that sinks in Alberta, the *arranged interchange* in each of the following circumstances:

**R1.1** If a *pool participant* is not involved in the *interchange transaction*.

**R1.2** If the *interchange transaction* is a bilateral *inadvertent interchange* payback.

### **5. Processes and Procedures**

No procedures have been defined for this *reliability standard*.

### **6. Measures**

The following measures correspond to the requirements identified in Section 4 of this *reliability standard*. For example, MR1.1 is the measure for R1.1.

**MR1.1** *E-tags*, voice recordings, or other documentations exist and are provided upon request, and can be used to confirm that an *arranged interchange* was submitted to the *interchange authority*.

**MR1.2** *E-tags*, voice recordings, or other documentations exist and are provided upon request, and can be used to confirm that an *arranged interchange* was submitted to the *interchange authority*.

### **7. Appendices**

No appendices have been defined for this *reliability standard*.

### **8. Guidelines**

No guidelines have been defined for this *reliability standard*.

## INT-001-AB-3 Interchange Information

---

### Revision History

Effective	Description
0000-00-00	
0000-00-00	