

INT-010-AB-1 Interchange Coordination Exemptions

1. Purpose

The purpose of this *reliability standard* is to allow certain types of *interchange schedules* to be initiated or modified by *reliability entities*, and to be exempt from compliance with other *interchange standards* under abnormal operating conditions.

2. Applicability

This *reliability standard* applies to:

- *ISO*

3. Definitions

Italicized terms used in this *reliability standard* have the meanings as set out in the Alberta Reliability Standards Glossary of Terms and Part 1 of the ISO Rules.

4. Requirements

R1 If the *ISO* experiences a resource loss covered by a reserve sharing agreement and the use of the energy from such agreement exceeds 60 minutes from the time of such loss, the *ISO* must submit to the *interchange authority* an *arranged interchange* with a start time no more than 60 minutes from the time of the resource loss.

5. Processes and Procedures

No procedures have been defined for this *reliability standard*.

6. Measures

The following measures correspond to the requirements identified in Section 4 of this *reliability standard*. For example, MR1 is the measure for R1.

MR1 Evidence exists and confirms that an *arranged interchange* is submitted and the start time is as specified in R1.

7. Appendices

No appendices have been defined for this *reliability standard*.

8. Guidelines

No guidelines have been defined for this *reliability standard*.

INT-010-AB-1 Interchange Coordination Exemptions

Revision History

Effective	Description
0000-00-00	
0000-00-00	