

New ISO Rules Definitions for Alberta Reliability Standards

New definitions required for FAC-003-AB-1 Transmission Vegetation Management Program:

“*transmission facility*” has the same meaning as given in the *Electric Utilities Act*.

"*Transmission Vegetation Management Program*" or "*TVMP*" means a plan for vegetation management work to ensure the reliability of electric transmission systems.

New definitions required for INT-003-AB-2 Interchange Transaction Implementation:

“*Adjacent Balancing Authority*” means a “Balancing Authority Area” as defined in the *NERC Glossary*;

"*Balancing Authority*" means a “Balancing Authority” as defined in the *NERC Glossary*;

“*Balancing Authority Area*” means a Balancing Authority Area as defined in the *NERC Glossary*;

“*compliance monitor*” means the entity(s) appointed by the *Commission* to carry out compliance monitoring of *reliability standards*.

"*High Voltage Direct Current*" or "*HVDC*" means a high voltage direct-current power *transmission facility* that uses direct-current to transfer power.

"*interchange*" means energy transfers that cross *Balancing Authority* boundaries.

“*interchange transaction*” means an “Interchange Transaction” as defined in the *NERC Glossary*;

“*NERC Glossary*” means the Glossary of Terms used in Reliability Standards published by *NERC* on its web site as amended from time to time;

"*Receiving Balancing Authority*" means a “Receiving Balancing Authority” as defined in the *NERC Glossary*;

"*schedule*" means a “Schedule” as defined in the *NERC Glossary*;

"*scheduling path*" means the transmission service arrangements reserved by a *market participant* for an *interchange transaction*;

"*Sending Balancing Authority*" means a “Sending Balancing Authority” as defined in the *NERC Glossary*;

New ISO Rules Definitions for Alberta Reliability Standards

New definitions required for TOP-005-AB-1 Operational Reliability Information:

"*interchange schedule*" means an "Interchange Schedule" as defined in the *NERC Glossary*;

"*interchange transaction*" means an "Interchange Transaction" as defined in the *NERC Glossary*;

"*Interconnection Reliability Operating Limits*" or "*IROL*" means "Interconnection Reliability Operating Limits" as defined in the *NERC Glossary*;

"*peak demand*" means "Peak Demand" as defined in the *NERC Glossary*;

"*system operating limit*" means "System Operating Limit" as defined in the *NERC Glossary*;

"*transmission operator*" means "Transmission Operator" as defined in the *NERC Glossary*;