






Alberta Interconnected Electric System Map



Substation Identification

*Land Locations are listed by Township-Range-Meridian. Township #s run South to North, Range #s East to West from each Meridian and are shown in the map. Meridians are shown at the top and bottom of the map.



Updated 2025-02-05

The map and associated information is provided by the ASES on an "as is" basis. The ASES makes no representations, warranties, or guarantees, express or implied, as to the accuracy, reliability, completeness, currency, or non-infringement of the map and associated information or that it will be suitable for any use. The ASES accepts no responsibility, either in law or in equity, or for any loss, damage, or cost incurred by the user or anyone else as a result of the use, conversion, publication, transmission, reproduction, or modification of the map and associated information, even if such losses or costs are foreseeable or preventable. The ASES and its licensors shall not be responsible for any loss, damage, or cost incurred by the user or anyone else as a result of the use, conversion, publication, transmission, reproduction, or modification of the map and associated information, even if such losses or costs are foreseeable or preventable.

3000, 240 - 4 Avenue SW, Calgary, Alberta T2P 4H4 Phone: 403-539-2450 Fax: 403-539-2949

www.aeso.ca