

# ISO Rules

## Part 300 System Reliability and Operations

### Division 303 Interties

#### Section 303.1 Load Shed Service



External Consultation Draft

October 22, 2018

#### Applicability

- 1 Section 303.1 applies to:
  - (a) a **market participant** that contracts with the **ISO** to provide **load shed service**; and
  - (b) the **ISO**.

#### Requirements

##### Providing Data

- 2 The **market participant** must provide the **ISO** with any information related to the provision of **load shed service** that the **ISO** requires in order to properly administer the service and must do so in real time via systems the **ISO** designates.

##### Determining Amount to Arm

- 3(1) The **ISO** must use current **Alberta internal load** levels and the net import schedule of the combined British Columbia and Montana transfer paths to determine the amount of **load shed service** that the **ISO** must arm.
- (2) When arming the required amount of service, the **ISO** must prioritize the arming of available **load shed service** so as to minimize expected cost.
- (3) The **ISO** must set the **load shed service** arming level at the beginning of the scheduling hour but may modify it if the requirement changes during the scheduling hour.

##### Restoring Service

- 4 After the operation of **load shed service**, while maintaining the **reliability** of the **interconnected electric system**, the **ISO** must restore the following in the following order:
  - (a) **contingency reserves**; then
  - (b) **load shed service**.

##### Arming and Disarming Service

- 5(1) The **ISO** will issue **dispatches** to arm and disarm **load shed service**.
- (2) The **market participant** must arm and disarm services in accordance with any **dispatches** the **ISO** issues unless the **market participant** identifies a circumstance that, in the **ISO**'s opinion, amounts to an event of **force majeure** that would prevent the **market participant** from complying with a **dispatch**.

##### Determining the Alberta Internal Load Range

- 6 If the estimated **Alberta internal load** falls right on, or very close to, the boundary of one of the ranges the **ISO** identifies, the **ISO** will use the lower **Alberta internal load** range to determine the amount of **load shed service** to arm during the hour that the **Alberta internal load** is expected to be at, or near, the boundary.

# ISO Rules

## Part 300 System Reliability and Operations

### Division 303 Interties

#### Section 303.1 Load Shed Service



#### Curtailing Import during the Scheduling Hour

**7** If there is insufficient **load shed service** due to the unavailability of this service, the **ISO** must adjust the import transfer level to the level corresponding to the required amount.

#### Restoring Service

**8** The **market participant** must not restore **load shed service** that has been tripped until the earlier of one (1) hour after tripping or the **ISO** authorizing such restoration.

#### No Double-Counting

**9** The **market participant** must not use the MWs it uses to provide **load shed service** under this section of the **ISO rules** to also simultaneously provide **ancillary services** under any other section of the **ISO rules** or under any contract.

#### Revision History

Date	Description
20xx-xx-xx	Revised subsection 3(3)
2013-07-01	Amendments made to accommodate the energization of MATL
2011-04-01	Initial release